

Speakerset 2



DESCRIPTIVE
DLE 591
March 1967


TELEPHONE
APPARATUS

This compact unit incorporates an amplifier, loudspeaker, volume control and on-off switch, housed in a neat plastic case. It amplifies incoming speech and is most useful for the customer who wishes to have both hands free so that he can write while waiting for a call to be answered, or make notes more easily during a telephone call. It also enables incoming speech to be heard by a small group of people.

The speakerset 2 can be associated with telephones connected to exclusive and shared exchange lines, most types of extensions, and private circuits.



SPEAKERSET 2



FACILITIES (Normal arrangement)

The speakerset can be switched on at any time during a call; this transfers reception from the telephone receiver to the loudspeaker in the set and disconnects the telephone. The on-off switch shines with an amber light while the speakerset is on.

When switched on, the speakerset holds the line engaged and the telephone handset can be laid on the desk.

A control is provided to adjust the volume of sound; an arrow indicates the direction for increase volume.

During a call the line can be re-connected to the telephone handset at any time by switching off the speakerset.

At the end of a call the line is restored, for normal use, by switching off the speakerset and replacing the handset.

FACILITIES (Handset control)

The speakerset can be controlled from the handset which is provided with a button. Normally, when the handset control is used, the speakerset switch is left pressed down and the handset button released. Both controls are then 'on', but the speakerset is cut off while the handset is on its rest.

Calls are made by lifting the handset and laying it on the desk, listening for dialling tone from the speakerset and dialling the number. When the called subscriber answers, the handset is raised and the button operated to speak. This also silences the speakerset.

During the call the button can be released so that other people in the room can hear, and pressed when the user speaks.

At the end of the call the handset button may be released, ready for the next outgoing call. When the handset is restored to its rest the speakerset is cut off.

GENERAL INFORMATION

The speakerset can be associated with the main and extension telephones of plans 1, 1A, 9, 12A, 108 and 108A, and with the main telephone only of plans 105, 105A, 107 and 107A.

The speakerset case measures 4" by 4" by 3", and it can be supplied in black, grey, and ivory; it stands near the telephone.

A separate power unit is not provided as the amplifier draws its power supply from the telephone line.

Rental and connexion charges are quoted in the preface sheet