

EQUIPMENT MANUAL 75

creed

M O D E L

Seventy-Five

T E L E P R I N T E R

Creed & Company Limited

H O L L I N G B U R Y

B R I G H T O N S U S S E X

Telephone BRIGHTON 507111

Telex 87169

Cables TELEPRINTA Telex BRIGHTON



ASSOCIATED PUBLICATIONS

Sales Publication 041-010-2E

Manual Issue Date October 1965

© 1965 by Creed & Company Limited

Printed in England by Specialised Printing Services Ltd., Harford House, 7/9 Charlotte Street, London, W.1.



MODEL SEVENTY-FIVE TELEPRINTER

INTRODUCTION

This equipment manual contains technical data, technical description, installation, maintenance, lubrication, adjustment instructions and parts list for a standard Creed Model Seventy-five Page Teleprinter. A standard model is defined as a Transmitter-Receiver fitted with Reperforating Attachment, Two-Colour Printing, Answer-Back, Operation Counter and Automatic Carriage-Return/Line-Feed facilities. Special applications of the teleprinter will be covered by Appendices suitable for insertion in Part 6 of this manual, and will be obtainable on request.

The manual supersedes Instruction Book No.75 (4th Edition) and Parts List No.1075 (3rd Edition). All relevant changes and additions to these two books have been incorporated in this manual. Any future changes will be issued in the form of loose-leaf amendment sheets and, when received, they should be actioned and entered up on the Amendment Record Sheet provided on the following page.

References to 'front', 'rear', 'left-hand' and 'right-hand', whether for units or the complete machine, are based on an operator's view of the machine unless otherwise stated. Thus the keyboard is at the front and the Reperforating Attachment on the right-hand side.

In this manual, explanatory notes underneath portions of the text are shown in two forms, i.e. ■ or ★. It is important that engineers are aware of the difference between the two symbols, as follows.

- This symbol is used whenever there is a possibility of damage to the machine or personal injury to the engineer if the technical content of the note is ignored. In isolated instances, it is also used to stress the importance of a particular note.
- ★ This symbol is used for normal technical or explanatory notes to the text.

For the benefit of customers outside the U.K. who may use a metric measurement system, an Imperial/Metric conversion table is provided in Part 6, Appendix A.

AMENDMENT RECORD SHEET

AMENDMENT NO.	AMENDED BY	DATE	AMENDMENT NO.	AMENDED BY	DATE
1			26		
2			27		
3			28		
4			29		
5			30		
6			31		
7			32		
8			33		
9			34		
10			35		
11			36		
12			37		
13			38		
14			39		
15			40		
16			41		
17			42		
18			43		
19			44		
20			45		
21			46		
22			47		
23			48		
24			49		
25			50		

P A R T 1 DATA SUMMARY AND TECHNICAL DESCRIPTION

P A R T 2 INSTALLATION AND OPERATION

P A R T 3 MAINTENANCE AND LUBRICATION

P A R T 4 ADJUSTMENTS

P A R T 5 DISMANTLING AND ASSEMBLING

P A R T 6 APPENDICES

P A R T 7 PARTS LIST